

NEC ELITE
TIME CHANGE PROCEDURES

Changes must be performed from attendant's position or main telephone:

- Press **FEATURE** button.
- Enter **9#**.
- Enter **TIME** on dial pad.
- Use **RECALL** key to change am/pm status.
- Press **FEATURE** button to end programming; or
- Press **HOLD** to change to calendar setting.
- Press **RECALL** to select day of week.
- Enter **#** to move the cursor to day of month field.
- Enter day of month via dialpad.
- Press **RECALL** to select month.
- Enter **#** to move the cursor to year field.
- Enter last two digits of year via dialpad.
- Press **FEATURE**.